Available Ericsson equipment at Launch 3

Please contact me at Allison.Chowanec@launch3.net if you are interested in any of the equipment listed below.

Part Number	Manufacturer	description
1316MCLICK	Ericsson	MINIATURE CLICK CONSUMABLE
2/RPM11350/02000	Ericsson	2/RPM11350/02000
2000000744	Ericsson	FALSE
2000000744	Ericsson	FALSE
5/NTM201201/4	Ericsson	Ericsson 5/NTM201201/4 EARTHING KIT
501/BYB40501	Ericsson	BASE FRAME/INSTAL.INTERF.
501/BYB40501	Ericsson	BASE FRAME/INSTAL.INTERF.
513 2170/01200	Ericsson	POWER CABLE
702/BYB41501/08	Ericsson	GBF 9250 (Global Base Frame)
77701/00500	Ericsson	Ericsson RPM 777 01/0500, cable with connector
BDP 104 105/1	Ericsson	HEAT EXCHANGE MODULE
BFC 901 055/1	Ericsson	ERICSSON RBS 6601 GPS BRACKET
BFL 901 009/4	Ericsson	
BFL 901 009/4	Ericsson	
BFX 901 36/1	Ericsson	BB Subrack for RBS 3101
BFZ 611 15/35	Ericsson	MINI-LINK
		RYS110243/1
		UKL50115/35 R2A
		BFZ 611 15/35
		2010 38/35
		RADIO LINK EQUIPMENT
BGB9513010 10A	Ericsson	BGB9513010 10A
BGB9513030	Ericsson	BGB95130/30
BGK 901 14/1 R1C	Ericsson	AUH 02 Network Card BGK90114/1R1C
BGK 901 18/2	Ericsson	RBS 6201 R2D SHU 02 01 BGK90118/2
BGK90114/1	Ericsson	AUH 02
BGM 136 1002/1	Ericsson	R1D BGM1361002/1
BKB 902 50/1	Ericsson	BATTERY UNIT
BKG 901 18/2	Ericsson	SHU 0201
BKV 106 020/1	Ericsson	RBS 3518 Complete FCU BKV106020/1
BKV 106 135/1	Ericsson	FAN UNIT
BKV 106 135/1	Ericsson	FAN UNIT
BKV 301 216/120	Ericsson	R1A Fan Unit
BKV 301 216/166	Ericsson	FAN
BKV106 032/2	Ericsson	FAN UNIT
BKY 901 39/1	Ericsson	Kit Connector
BMF 904 77/5	Ericsson	DOU -48v/200A BMF904775
BMF904771	Ericsson	DOU 48v 125 Amp
BMG 136 1002/1	Ericsson	R1D BMG1361002/1

BMG 907 33/4	Ericsson	BFU34 BMG90733/4R5C
BMG 907 33/4 R4A	Ericsson	BFU34 BMG90733/4R4A
BMG 980 163/3	Ericsson	BFU -48V/100A STD R1B
BMG 980 168/3	Ericsson	R1B
		BFU -48V/STD CABLE 14470
BMG 980 168/3	Ericsson	R1B
		BFU -48V/STD CABLE 14470
BMG 980 26/18	Ericsson	Service outlet 10A
BMG 980 26/2	Ericsson	ACCU-32 ACCONECTION UN
BMG 980 26/2 R2A	Ericsson	ACCU-32 BMG98026/2R2A
BMG 980 33/1 R1C	Ericsson	PDU BMG98033/1R1C
BMG 980 33/1 R1C	Ericsson	PDU BMG98033/1R1C
BMG 980 33/22	Ericsson	R1A PDU 02 BMG98033/22
BMG 980 336/6	Ericsson	PDU 01 03
BMG 980 337/1	Ericsson	BFU 01 01 R4A
BMG 980 337/1	Ericsson	BFU 01 01 R4A
BMG 980 340/1	Ericsson	R1E PCU AC 01 CIRCUIT BREAKER
BMG 980 390/10	Ericsson	Optional AC Outlet Module with Emerson 85570606560 en
BMG 980 390/14	Ericsson	SERVICE OUTLET BMG980390/14
BMG907027/1	Ericsson	PDU
BMG980121	Ericsson	ADM-01
BMG980331	Ericsson	PDU-02
BMG9803362	Ericsson	PDU 01 01 R4J
BMG9803362	Ericsson	PDU 01 01 R4J
BMG980341	Ericsson	R1C. ADM-04 BMG98034/1
BMG980341	Ericsson	R1C. ADM-04 BMG98034/1
BMG9803410	Ericsson	ADM-04
BML 161 174/1	Ericsson	Standalone single Digital Unit DU PSU (Standalone single)
BML 161 174/1	Ericsson	Standalone single Digital Unit DU PSU (Standalone single)
BML 161 174/1	Ericsson	Standalone single Digital Unit DU PSU (Standalone single)
BML 353 132/2	Ericsson	R1A PSU-AC BML353132/2
BML 353 132/2	Ericsson	R1A PSU-AC BML353132/2
BML 353 132/2 R1A	Ericsson	PSU-AC BML353132/2R1A
BML 353 132/2 R1E	Ericsson	PSU-AC BML353132/2R1E
BML 353 132/2 R2G	Ericsson	PSU-AC BML353132/2R2G
BMR91120/1	Ericsson	DC/DC-C
BOE 602 15/2	Ericsson	IXU-21 UNIT BOE60215/2
BYB 91133/1	Ericsson	Base frame GBF 6102 EXT
C00119291-9144	Ericsson	Coax Cable - 201132 CA3
C00811964-002F	Ericsson	CONNECTION CABLE
C01611049-2600	Ericsson	CABLE, TELEPHONE
CEQ.31865	Ericsson	
CEQ.31866	Ericsson	RF co-site cable, SMA-7/16 90deg For RRUW
D001228 R2A	Ericsson	R2A Battery Spacer Kit (PKG QTY = 4)
F002S0551BLU-015M	Ericsson	Connection Cable
F002S0551BLU-0360	Ericsson	

HPGMT15	Ericsson	Fuse Panel
J48919-TKF421322/10	Ericsson	TELEPHONE CENTRAL OFFICE POWER CABLE
KDU 137 533/4	Ericsson	Standalone single Digital Unit DU Board PROCESSOR UN
KDU 137 569/1	Ericsson	GSM Baseband Unit KDU 137 569/1 GSM Baseband Unit
KDU 137 58/1	Ericsson	KDU137581/1 XCU 01 01
KDU 137 581/1	Ericsson	KDU137581/1 R1D
		XCU 01 01
KDU 137 581/1	Ericsson	KDU137581/1 R1D
		XCU 01 01
KDU 137 581/1	Ericsson	KDU137581/1 R1D
		XCU 01 01
KDU 137 581/1	Ericsson	KDU137581/1 R1D
		XCU 01 01
KDU 137 624/1	Ericsson	DUS 41 01
KDU1271613	Ericsson	ERICSSON RBS 6601 WCDMA BASEBAND PRNCD
KDY208032R1	Ericsson	KDY20803/2R1
KET10924/1	Ericsson	KET 109 24/1 TEMP SENSOR CABLE X50-E06506
KFE 10211/1	Ericsson	
KRC 112 15/3	Ericsson	R4B. TMA DDPX 1880-1910 MHZ
KRC 118 023/1	Ericsson	KRC1180231 AIR 21 LTE B2A B4P AIR PCS Kathrein 810
KRC 118 023/1	Ericsson	KRC1180231 AIR 21 LTE B2A B4P AIR PCS Kathrein 810
KRC 118 046/1	Ericsson	KRC1180461 AIR 21 B4A/B2P 2100MHz Antenna
KRC 118 046/1	Ericsson	KRC1180461 AIR 21 B4A/B2P 2100MHz Antenna
KRC 118 046/1	Ericsson	KRC1180461 AIR 21 B4A/B2P 2100MHz Antenna
KRC 118 21/1	Ericsson	KRC118211 sFU12 850 - Filter Unit RBS3206
KRC 118 29/2	Ericsson	RU2221 2IV40 2100 Radio
KRC 118 59/1	Ericsson	KRC11859/1 R3B RUS 01 B4
KRC 119 28/1	Ericsson	KRC119281 FU12 2100MHz
KRC 131 085/3	Ericsson	DPX + BIAS 1880 - 1910 MHz 99W44 R2A
KRC 131 146/1	Ericsson	RRU RRUS 11 Radio Type 3R Enclosure CDMA/LTE 1900
KRC 161 134/4	Ericsson	RRU22 21IV40 R2A
		KRC1611344
KRC 161 241/1	Ericsson	KRC161241/1RRUS 11 B12 RRU -48V Type 3R Enclosure
KRC 161 241/1	Ericsson	KRC161241/1RRUS 11 B12 RRU -48V Type 3R Enclosure
KRC 161 241/1	Ericsson	KRC161241/1RRUS 11 B12 RRU -48V Type 3R Enclosure
KRC 161 254/1	Ericsson	R1G RRUS 11 B4 TYPE 3R ENCLOSURE. Unit is missing
KRC 161 254/2	Ericsson	RRUS 11 B4 Type 3R Enclosure
		KRC1612542 Band 4 Radio R1H
KRC 161 287/2	Ericsson	RRU11 KRC1612872 Remote Radio Head
KRC11822/4	Ericsson	RU 22-850
KRC11847/2	Ericsson	RRUW-02 B2 1900 KRC11847/2
KRC118651	Ericsson	RBS 6201 R2A RUS 01 B3 R2A KRC11865/1 KRC 118 65
KRC121044	Ericsson	TRX
KRC121101	Ericsson	TRX
KRC121102	Ericsson	10 WATT TRX - 850 MHZ
KRC121103	Ericsson	30 WATT RADIO

KRC1311851	Ericsson	KRC1311851 R1B 1850-1910MHz Type 3R Enclosure TMA
KRC1311851	Ericsson	KRC1311851 R1B 1850-1910MHz Type 3R Enclosure TMA
KRE 1012082/1	Ericsson	GPS Antenna 26DBi + Bracket Huber Suhner 1315.17.0018
KRE 1012082/1	Ericsson	GPS Antenna 26DBi + Bracket Huber Suhner 1315.17.0018
KRE 1012082/1	Ericsson	GPS Antenna 26DBi + Bracket Huber Suhner 1315.17.0018
KRE 1012082/1	Ericsson	GPS Antenna 26DBi + Bracket Huber Suhner 1315.17.0018
KRF 102 272/4	Ericsson	Filter Unit
KRF1023241	Ericsson	Diplexer KRF102324/1 SL Filter 800 SMR Diplexer KRF102
KRF1023241	Ericsson	Diplexer KRF102324/1 SL Filter 800 SMR Diplexer KRF102
KRF1023241	Ericsson	Diplexer KRF102324/1 SL Filter 800 SMR Diplexer KRF102
KRF201892	Ericsson	1710-1990 MHz EHCU External Hybrid Combiner Unit
KRF201892	Ericsson	1710-1990 MHz EHCU External Hybrid Combiner Unit
KRY 101 1946	Ericsson	GPS Splitter R1A KRY1011946
KRY 101 1946	Ericsson	GPS Splitter R1A KRY1011946
KRY 101 1946	Ericsson	GPS Splitter R1A KRY1011946
KRY 112 37/1 R1C	Ericsson	TMA(Single Duplex Fullband)
KRY 112 89/1	Ericsson	R2A TMA Standard RX 1850-1910 MHz Type 3R Enclosure
KRY 112 89/5	Ericsson	KRY112895 Double TMA 1900-E 1850-1900MHz Type 3R
KRY 112 89/5	Ericsson	KRY112895 Double TMA 1900-E 1850-1900MHz Type 3R
KRY 901 212/2	Ericsson	RUS 01 B2 PAU KRY9012122 R1A
KRY1011587/1	Ericsson	KRY 101 1587/1
		TYPE 3S ENCLOSURE, RF, DC, RF/DC, BIAS INJECTOR
KRY1011587/1	Ericsson	KRY 101 1587/1
		TYPE 3S ENCLOSURE, RF, DC, RF/DC, BIAS INJECTOR
KRY1011587/1	Ericsson	KRY 101 1587/1
		TYPE 3S ENCLOSURE, RF, DC, RF/DC, BIAS INJECTOR
KRY1011884/1	Ericsson	KRY1011884/1 R2B TMA Bias Injector Kit with (2) KRY 101
KRY1011924/1	Ericsson	EXTERNAL CONTROL MODUL
KRY1011946/1	Ericsson	1X4 GPS ACTIVE SPLIT.
KRY112712	Ericsson	KRY112712 R1C. Dual Duplex Bypass TMA 1850-1910MH
KRY11276/1	Ericsson	Dual Duplex Bypass TMA 1850-1910 Mhz KRY11276/1
KRY11279/1	Ericsson	
KRY112812	Ericsson	Amplifier, Dual Duplex Tower Mounted Amplifier Fullband F
KRY112812	Ericsson	Amplifier, Dual Duplex Tower Mounted Amplifier Fullband F
KRY11289/4	Ericsson	AMPLIFIERDouble TMA 1900
MINI-RE2-CABLEKIT	Ericsson	RA&B ,CABLE_KIT, CABLING KIT SPECIFIC
N1010454/2S1	Ericsson	Signal Cable N1010454/2s2
NBA 101 041/1	Ericsson	NBA100411
NCD 901 26/11	Ericsson	NCD90126/11 R2F OVP-TRM1 X11
NCD 901 26/11	Ericsson	NCD90126/11 R2F OVP-TRM1 X11
NCD 901 26/13	Ericsson	RBS 3518 Complete OVP-ALM1 NCD90126/13
NCD 901 26/13	Ericsson	RBS 3518 Complete OVP-ALM1 NCD90126/13
NCD 901 38/1	Ericsson	ERICSSON RBS 6601 GPS RECEIVER
NCD 901 41/1	Ericsson	Standalone single Digital Unit GPS Recevier GPS 02 01; G
NCD 901 41/1	Ericsson	Standalone single Digital Unit GPS Recevier GPS 02 01; G
NES30-PS-033	Ericsson	

NES39-PS-033	Ericsson	YELLOW CABLE
NES40-PS-021	Ericsson	
NFD 302 34/08	Ericsson	OVP-ALM8 External Alarms
NFD 302 34/08	Ericsson	OVP-ALM8 External Alarms
NFT 304 43/4	Ericsson	R1A ZGZD4-20-48K1 SURGE PROTECTION Zhongguand
NFT 304 59/2	Ericsson	EF-114210-01 R1C SURGE PROTECTION SPD -48 VDC
NFT 304 59/2	Ericsson	EF-114210-01 R1C SURGE PROTECTION SPD -48 VDC
NGC 901 45	Ericsson	SURGE ARRESTOR FREQUENCY 698-2700MHZ
NGC 901 45	Ericsson	SURGE ARRESTOR FREQUENCY 698-2700MHZ
NGC 901 45	Ericsson	SURGE ARRESTOR FREQUENCY 698-2700MHZ
NGC 901 45	Ericsson	SURGE ARRESTOR FREQUENCY 698-2700MHZ
NGC 901 45/1	Ericsson	
NGT21104/6	Ericsson	NGT211046 Earthing Kit, Radio Cable 7.6mm, for mini-link Anixter #604624
NTDV24AA	Ericsson	B- VBTS AC INTERFACE MODULE WITHOUT AC OUTLE
NTGZ70BBE5	Ericsson	Nortel MFRM III 1900MHz Radio NTGZ70BB
NTM 101 0794/4	Ericsson	R1B CABLE LUG KIT
NTM 101 0794/4	Ericsson	R1B CABLE LUG KIT
NTM 101 1031/1	Ericsson	M10
NTM 203 220	Ericsson	
NTM1010429/1	Ericsson	Mounting brackets, RRUS wall install, can be used with 2G
NTM1011081/1	Ericsson	RBS 3206 CABLE
NTM101381/4	Ericsson	XTERNAL ALARM CONTROL UNIT
NTM101804/2	Ericsson	Kit: Grounding kit, 50mm black 3 meter
NTM201 3977/1	Ericsson	SCREW KIT KIT CONTAINING PART #'S SBM12305/8 78/SBA121060/0160 SBF89942/1 SET10302
NTM2012977/1	Ericsson	SHIELD ANCHOR SET 110mm (4 IN A PACK)
NTM2013351/1	Ericsson	R1A CABLE BUSHING CONNECTION MATERIAL
NTM2013729/1	Ericsson	Ericsson NTM 201 3729/1 Cable Winder Box
NTM2013729/1	Ericsson	Ericsson NTM 201 3729/1 Cable Winder Box
NTM202	Ericsson	Antenna Mounting Bracket
NTM20220/1	Ericsson	SET OF 2 Tower Mast Bracket
NTM203058/22	Ericsson	CLAMP KIT, 10 MM
NTM20373/2	Ericsson	Cable clamp kit 50
NTM20398/100	Ericsson	TZC 500 95, 100M
NTM20398/50	Ericsson	TZC 500 95, 50M

NTM2570004/1	Ericsson	Assembly, Base Frame Roxtec
NTMU 201 3230/2	Ericsson	ntmu20132302 Antenna Mount Kit
NTMU 201 3230/2	Ericsson	ntmu20132302 Antenna Mount Kit
NTMU 201 323012	Ericsson	MOUNTING POLE WITH HARDWARE
NTQA66GA	Ericsson	NTQA66GA 01
		S8000 BTS BCF Cage
R0F367 2021 R8F	Ericsson	R0F367 202/1 R8F
RBS 3518	Ericsson	Suburban Rooftop Site solution for
		WCDMA W/ (1) BFE 401 1018 P55 TYPE 3R, (1) BMG 907
		(1)ROJ 119 2315/2 R1A ET-MFX, (4) ROJ 119 2187/14 R1
		2238/22 R1F. OBIF, (1) BKV 106 020/1 R1F. FCU, (1) BMC
		TRM1
RBS 6601	Ericsson	R1C LTE w/ (1) 506/BFL 901 009/1, (1) KDU 127 161/3 DU
		RPM 777 01/00180 Signal cable,(1) RPM 777 193/00160 C
		with Connector RBS6601
RBS 6601	Ericsson	R1C LTE w/ (1) 506/BFL 901 009/1, (1) KDU 127 161/3 DU
		RPM 777 01/00180 Signal cable,(1) RPM 777 193/00160 C
		with Connector RBS6601
RDH 102 47/1	Ericsson	Transceiver
RDH 102 47/2	Ericsson	2.5Gbit/s 8km CPRI TRF5736AVLB243 SFP optical transce
RDH 102 47/3	Ericsson	2.5Gbps 1310nm 15km SFP Fiber Optic Module
RDH10245/1	Ericsson	ERICSSON SEA 20 SFP TRANSCEIVER
RDH10245/1	Ericsson	ERICSSON SEA 20 SFP TRANSCEIVER
RFSBA189100/0250	Ericsson	SCREW M6S-M 10X25H RFST KIT OF 4
RMF89928/1	Ericsson	R1D UMTS SWITCH/AC CB | 13521
RMF89928/1	Ericsson	R1D UMTS SWITCH/AC CB | 13521
RNT 447 19/001	Ericsson	DC Power Cable Connector RRUS 01
RNT44719	Ericsson	Amphenol
ROF1375291-1RGA	Ericsson	and ROF1975201/1R4A
ROFU1310019-1R7A-A	Ericsson	and ROFU1320018/1R7A/A
ROJ 119 2163/1	Ericsson	ET-MC1 ROJ 119 2163/1 ET-MC1
ROJ 119 2187/14	Ericsson	RAX Board
ROJ 119 2187/14	Ericsson	RAX Board
ROJ 119 2187/14	Ericsson	RAX Board
ROJ 119 2187/14 R1D	Ericsson	RAX
ROJ 119 2254/6	Ericsson	RBS 3518 Complete TX6HS-06 ROJ1192254/6
ROJ 119 2254/6	Ericsson	RBS 3518 Complete TX6HS-06 ROJ1192254/6
ROJ 119 2254/8	Ericsson	ROJ1192254/8
ROJ 119 2254/8	Ericsson	ROJ1192254/8
ROJ 119 2315/2	Ericsson	RBS 3518 Complete ET-MFX ROJ1192315/2
ROJ 119 2315/2	Ericsson	RBS 3518 Complete ET-MFX ROJ1192315/2
ROJ 119 2315/2	Ericsson	RBS 3518 Complete ET-MFX ROJ1192315/2
ROJ119218710	Ericsson	RAXB R2 (128CE)
ROJ11921874	Ericsson	RAX 13 ROJ1192187/4
ROJ11922091	Ericsson	RBS 3518 Complete CBU1 ROJ1192209/1
ROJ11922091	Ericsson	RBS 3518 Complete CBU1 ROJ1192209/1

ROJ1192238/22	Ericsson	OBIF Card
ROJ11922452	Ericsson	TXB R3 (256CE)
ROJ11922452	Ericsson	TXB R3 (256CE)
ROJ11922544	Ericsson	TX6MS-O4
ROJ11922544	Ericsson	TX6MS-O4
ROJ2071101R1B	Ericsson	OO-HD Card
ROJ208138/1	Ericsson	PEBV4(included)
ROJ208143/10	Ericsson	IBASV4(included)
RPM 113 6127/15M	Ericsson	RPM1136127/15MR2A nterface Cable Eth Straight 15M
RPM 113 6127/2000	Ericsson	R2A BH2 Interface Cable Eth Straight
RPM 113 6127/2000	Ericsson	R2A BH2 Interface Cable Eth Straight
RPM 253 1633/50M	Ericsson	2F LC-LC 5M RRUS02, RRUS11
RPM 253 2895/5000	Ericsson	2F LCD-LCD SM RRUW01 CASCADE 5M
RPM 253 3577/100M	Ericsson	2F LCD-LCD SM RRUM01
RPM 253 3577/20M	Ericsson	2F LCD-LCD SM RRUW01 3418/3518 FIBRE OPTIC CABI
RPM 253 3577/50M	Ericsson	RPM2533577/50M 2F LCD-LCD SM RRUW01 3418/3518 I
RPM 253 4388/3000	Ericsson	2F SM RDC-LCD RRU 3M CABLE
RPM 253 4388/3000	Ericsson	2F SM RDC-LCD RRU 3M CABLE
RPM 253 4388/3000	Ericsson	2F SM RDC-LCD RRU 3M CABLE
RPM 253 4692/3000	Ericsson	R1A 2F OCD-LCD W/ Cover 3M RPM25346923000 LCD-2
RPM 253 4692/3000	Ericsson	R1A 2F OCD-LCD W/ Cover 3M RPM25346923000 LCD-2
RPM 253 4692/5000	Ericsson	R1A 2F SM ODC-LCD W/ Cover 5M RPM25346925000
RPM 253 4692/5000	Ericsson	R1A 2F SM ODC-LCD W/ Cover 5M RPM25346925000
RPM 513 1673/00350	Ericsson	PWR CABLE RBS3000
RPM 513 1811/01000	Ericsson	R1C Connection Cable X50
RPM 513 1811/01000	Ericsson	R1C Connection Cable X50
RPM 513 1891/0200	Ericsson	
RPM 513 1891/02000	Ericsson	SIGNALING CABLE
RPM 513 1948/00400	Ericsson	CABLE
RPM 513 2110/01000	Ericsson	CABLE WITH CONNECTOR
RPM 513 2165/00500	Ericsson	CABLE WITH CONNECTOR
RPM 513 2165/00700	Ericsson	R2A CABLE WITH CONNECTOR RPM5132165/00700
RPM 513 2165/00700	Ericsson	R2A CABLE WITH CONNECTOR RPM5132165/00700
RPM 513 2170/01200 R2A	Ericsson	POWER CABLE
RPM 513 2171/01100 R1B	Ericsson	CABLE WITH CONNECTOR E 00553
RPM 513 2195/00370	Ericsson	POWER CABLE
RPM 513 2274/01500	Ericsson	CABLE
RPM 777 01/00180	Ericsson	Signal Cable
RPM 777 01/00400	Ericsson	R1B. Signal Cable T.A. RPM77701/00400
RPM 777 01/00400	Ericsson	R1B. Signal Cable T.A. RPM77701/00400
RPM 777 01/00500	Ericsson	R1B. SIGNAL CABLE. RPM77701/00500
RPM 777 01/00500	Ericsson	R1B. SIGNAL CABLE. RPM77701/00500
RPM 777 01/00700	Ericsson	R2A CABLE WITH CONNECTOR RPM77701/00700

RPM 777 01/00700	Ericsson	R2A CABLE WITH CONNECTOR RPM77701/00700
RPM 777 01/00700	Ericsson	R2A CABLE WITH CONNECTOR RPM77701/00700
RPM 777 01/01000	Ericsson	R1A. signal cable
RPM 777 01/01000	Ericsson	R1A. signal cable
RPM 777 01/01200	Ericsson	Signal Cable
RPM 777 01/01300	Ericsson	Signal Cable T.A.
RPM 777 01/01300	Ericsson	Signal Cable T.A.
RPM 777 01/01300 R1B	Ericsson	Signal Cable T.A. RPM77701/01300R1B
RPM 777 01/01300 R1B	Ericsson	Signal Cable T.A. RPM77701/01300R1B
RPM 777 01/02000	Ericsson	Signal Cable
RPM 777 01/02600	Ericsson	
RPM 777 01/0700	Ericsson	R1B SIGNAL CABLE RPM77701/0700
RPM 777 04/01180	Ericsson	Gamma 3 Cable (RU- RUIF) | 31221
RPM 777 05/00320	Ericsson	COAXIAL CABLE
RPM 777 05/00460	Ericsson	